

### Manual Brel 1-channel and 15-channel emitter Type DC-2700 and DC-2702

Read the manual before you begin the installation. If these instructions are not followed, this may lead to defects and injury in which warranty can't be claimed.

#### Technical specifications

- Battery type:
- Frequency::
- Emission power:
- Emission distance:


#### Type DC-2700 and DC-2702

1x CR2450  
433,92MHz  
10 MW  
200 meter open field, 2 walls 35 meter.


#### Button specifications



#### Change battery




#### Set up number of channels



In programming mode; press the up or down button. You can stop quickly.

If you want to change the locked channels, you can reset.

#### Teaching multiple channels



To delete one channel , you must repeat the above operation.

#### Connecting the emitter to these electronic motors; MEV, MCE, MDE, MLE, MJE, MTE, MEQ, MPE, MG, MGLE.

1x P1

Hold  $\Delta V$



Hold the P1 button until the motor has moved once and (beeps).

Press up and down at the same time (beeps 7x) until the motor moves up and down.